


INSTALLATION INSTRUCTIONS


1. Prepare door for exit device. See exit device instructions for holes, line X-X, and center lines.
2. Prepare door for trim:
 - A. Transfer line X-X from inside (exit device side) of door to outside (trim side) of door. Use extra care if edge of door is beveled. Be sure center line X-X is parallel to edge of door.
 - B. Locate and prepare holes as shown.
3. Prepare trim:
 - A. For NL function, remove TP adapter cam and install NL adapter cam (see other side).
 - B. For NL or TP functions, change handing if necessary (see other side).
 - C. For NL or TP function, install cylinder (see other side).
4. Apply trim.
5. Apply exit device.



For cutouts on inside face of door, see exit device instructions

VON DUPRIN

337DT/TP-NL TRIM
FOR 33/3527 DEVICE ON WOOD DOOR






921033-00

PAGE NO.
1 of 2

REVISION
B

921033-00



Customer Service
1-877-671-7011 www.allegion.com/us

ALLEGION
© Allegion 2015
Printed in U.S.A.
921033-00 Rev. 06/15-b

VON DUPRIN

337DT/TP-NL TRIM
FOR 33/3527 DEVICE ON WOOD DOOR

921033-00

PAGE NO.
2 of 2

REVISION
B