

GLYNN-JOHNSON

HL6L PUSH-PULL LEAD LINED LATCH INSTALLATION TEMPLATE



NOTE: DIMENSIONS IN () ARE IN MILLIMETERS


TEMPLATE NUMBER:


INST.HL6L_B.PG1

DATE: 05-29-15



- A. WRAP LEAD AROUND LATCH BOLT. B. INSTALL LATCH BOLT ASSEMBLY WITH RADIUS SIDE OF LATCH BOLT ON THE PUSH SIDE OF DOOR.
- REMOVE COVERS FROM HANDLE ASSEMBLY. CHECK THE CAM POSITION ON THE PUSH HANDLE ASSEMBLY (SEE CHART).
- INSTALL PUSH HANDLE ASSEMBLY WITH LOCK SHAFT THRU LATCH BOLT ASSEMBLY. PLACE LEAD WASHER AROUND LOCK SHAFT.
- G. CHECK THE CAM POSITION ON THE PULL HANDLE ASSEMBLY (SEE CHART).
- INSTALL PULL HANDLE ASSEMBLY WITH LOCK SHAFT INSERTED INTO CAM.
- SECURE WITH SCREWS AND NUTS.
- J. INSTALL COVERS.





GLYNN-JOHNSON

HL6L PUSH-PULL LEAD LINED LATCH INSTALLATION TEMPLATE

a **ALLEGION**

NOTE: DIMENSIONS IN () ARE IN MILLIMETERS

TEMPLATE NUMBER:

INST.HL6L B.PG2

DATE: 05-29-15