



931218-00

# 6211WF/6211WFDS

# VON DUPRIN


Electric Strike, Single Door Wood Frame Mortise or Cylindrical Application

Installation Instructions

**Notes:** Deadbolt will not function with this strike. Check with factory for retrofit applications.

1. For lock or device preparation, see their directions.
2. Prepare frame for strike (see other side).
3. Wire strike (Figure 1). (Switches on 6211WFDS only.)
4. Test strike: Apply solenoid power. Fail secure (FSE) lip unlocks. Fail safe (FS) lip locks. Figure 1 shows status of switches.
5. Install strike with two #12-24 screws. Make sure clearance between latch bolt and strike lip is 1/32" (Figure 2). If not, uninstall strike, adjust (Figure 3), and reinstall.
6. If latch bolt does not extend far enough to actuate tripper, install extension (Figure 4). (Tripper on 6211WFDS only.)
7. Test door: With strike unlocked, door opens with latch bolt extended. When door closes, latch bolt rides over strike lip.

### TVS Installation Recommended



### SOLENOID POWER REQUIREMENTS

Yellow solenoid wires: 12 VDC, 0.57 A  
 Black solenoid wires: 24 VDC, 0.29 A  
 (also shown on strike label)




Figure 1

### SWITCH RATINGS

Standard: 5 A, 30 VDC  
 Gold: 0.25 A, 30 VDC




Figure 2

To adjust strike, loosen screws A, B, and C and move backbox sideways as necessary




Figure 3

**NOTE:**  
 Static Strength Rating 1500 lb.  
 Dynamic Strength Rating 70ft.-lb.  
 Endurance Rating 250,000 c.







Figure 4



89/336/EEC



**Door Preparation for Strike**



**Strike Dimensions and Required Clearances**