


25-V Surface Vertical Device on ANSI A115.2 Prepared Door

Surface Vertical Rod Panic Exit Devices, Wood Door, LHR Shown, RHR Opposite



BACKSET		
Installation	4\"/>	
Two Vertical Rod Devices	—	2 3/4\"/>
Vertical Rod x Mortise Device	2 3/4\"/>	
Vertical Rod x Rim Device (1609 strike)	2 3/4\"/>	

- Drill 1/8" (3 mm) diameter x 1" (25 mm) deep, or refer to Template W-4014 for sexbolt preparation (8 holes).

- For exit only device or device with non-thrumbing trim, drill 1/8" (3 mm) diameter x 1" (25 mm) deep, or refer to Template W-4014 for sexbolt preparation (4 holes).
- For device with thrumbing trim, refer to trim template.

- For exit only device, drill 2" diameter, half of door thickness depth. For trim applications, drill through.

- For applications over 8 feet, install two rod guides equally spaced on top rod.
- For Less Bottom Rod (LBR) application (20 minute rating), refer to template W-5494 for auxiliary fire latch preparation, and omit bottom rod preparation.
- For sexbolt preparation, refer to Template W-4014.
- For outside trim, see trim template for door preparation.
- For ANSI A115.2 doors, the center line of the ANSI 2 1/8" cutout must be within a height range of 38" to 42.5" and center line of exit device cannot be changed from 40.25"
- On ANSI A115.2 doors, the NL-OP option may not work depending on the vertical location of the ANSI 2 1/8" cutout

**TEMPLATE
W-1261-a**