

Mark center of door
thickness for 1" (25mm)
dia. hole.

SCHLAGE®

Template

B200-Series adjustable backset
adjusts for either 2³/₈" (60mm) or
2³/₄" (70mm) backsets.

Fold on door edge.


Important: Place template on
high edge of door bevel.

Recommended height from
center of deadbolt to center of
lock is 4" (10cm).

Select correct backset
2³/₈" (60mm) or 2³/₄" (70mm)

2³/₈" (60mm) 2³/₄" (70mm)

Drill 2¹/₈" (54mm) hole.



INGERSOLL-RAND
ARCHITECTURAL HARDWARE

©1999 Schlage Lock Co.

Printed in USA 4/99


P513-326 B260/B262

SCHLAGE®

Plantilla

Importante: Coloque la plantilla sobre el borde alto del bisel de la puerta. La distancia recomendada entre el centro del cerrojo y el centro de la cerradura es de 10cm.

Marque el centro del espesor de la puerta para hacer un agujero de 25mm



Tracez le point central de l'épaisseur de la porte. Pour trou de 25mm.

Doble sobre el borde de la puerta. A plier sur l'arrête de la porte.

Gabarit

Important: Placez le gabarit sur le cote de l'arrête supérieure d'une porte a chanfrein. La hauteur recommandée du milieu du pêne dormant jusqu'au milieu de la serrure est de 10cm.

Escoja la distancia correcta de 60mm o 70mm.
Taladre un agujero de 54mm.

60mm 70mm

Sélectionnez la distance d'entrée correcte de 60mm ou 70mm. Percez un trou de 54mm.